



Börkey has used various color wires and switches through the years. The connections shown here have worked with most Börkey Rexa machines.

If the old wires are numbered 1, 2 and 3, try the connections shown at left.

If the old wires are numbered 1, 1 and 2, try the connections shown at right.

